

Lecture 7

Recall from last lecture...

- ① What is partition-y about a partition function?

$$\frac{P(A)}{P(B)} = \frac{\frac{Q_A}{Q}}{\frac{Q_B}{Q}} = \frac{Q_A}{Q_B}$$


The ratio of partition functions tells how probability partitions between two options.

- ② What is free about free energy?

$$dE = TdS - p\cancel{dV} + \mu dN^0$$


Work: Change in energy due to variables I manipulate

Heat: Change in energy due to flows into or out of the thermal bath. We don't get to use these flows - they're along for the ride.



In the **slow** process I have to do work to push particles out of the way but I go slowly enough that particles can diffuse out of the way on their own without my pushing.

In the **fast** process I'm too impatient to let them get out of the way on their own so I have to push harder than I would have in a reversible process.



$$\int_{\text{fast}} dt \frac{dE(t)}{dt} = E(N, V_f, T) - E(N, V_i, T)$$

$$\int_{\text{slow}} dt \frac{dE(t)}{dt} = E(N, V_f, T) - E(N, V_i, T)$$

shorthand $\Rightarrow \int_{\text{fast}} dE = \int_{\text{slow}} dE$

$$\Rightarrow \int_{\text{fast}} (dQ + dW) = \int_{\text{slow}} (dQ + dW)$$

(Sign convention: Positive W is work done on the system
 Positive Q is heat flow into the system)

The fast process effectively pushes against more molecules.


$$\Rightarrow \int_{\text{fast}} \delta w > \int_{\text{slow}} \delta w$$

Hence $\int_{\text{fast}} \delta Q < \int_{\text{slow}} \delta Q$

The fast process has MORE heat flow out of the system.

The best we'll ever do is to go slowly (reversibly) so that the gas gets to re-equilibrate before I push any more.

Reversible vs. Irreversible...



I visit different microstates unless I go slowly enough to visit equilibrium microstates in each direction

$$dW \geq dW_{\text{rev}}$$

A reversible transformation requires the least amount of work at fixed T.

In that reversible case...

$$dW_{\text{rev}} = -pdV, \text{ so}$$

$$dE = TdS - pdV$$

$$\Rightarrow dW_{\text{rev}} = dE - TdS$$

$$= d(E - TS) \Big|_T \quad \text{Fixed } T$$


$$= (dA) \Big|_T \quad \begin{array}{l} \text{Provided I am in} \\ \text{contact w/ a fixed} \\ T \text{ temperature bath.} \end{array}$$

$$dW \geq (dA)_T$$

The most work that can be extracted comes from a reversible transformation, in which case

$$W = \Delta A = A(N, V_f, T) - A(N, V_i, T)$$

These ideas extend beyond gasses and pistons.
They also apply to microscopic systems...



What am I going to measure? L

What am I not going to measure? H_2O molecules
interior monomers

My microstates ν are given by the polymer configurations

$$\nu = (L, \{x_i\})$$

\uparrow end-to-end distance everything else

$$P(\nu) = \frac{e^{-\beta E(\nu)}}{Q} \quad (\beta \text{ from } H_2O \text{ molecules})$$

What is $P(L)$? (Free polymer at this point -)
free to fluctuate that is)

$$P(L) \propto \sum_{\{i\}} e^{-\beta E(L, \{i\})}$$

Marginalize (average) over degrees of freedom I'm not measuring

$$\Rightarrow \ln P(L) = \ln(\text{const.}) + \ln \left(\sum_{\{i\}} e^{-\beta E(L, \{i\})} \right)$$

$$\Rightarrow \frac{\partial \ln P(L)}{\partial L} = \frac{\beta \sum_{\{i\}} \left(-\frac{dE(L, \{i\})}{dL} \right) e^{-\beta E(L, \{i\})}}{\sum_{\{i\}} e^{-\beta E(L, \{i\})}}$$

The statistical weight for microstate $\{i\}$ when L is fixed

$$P(\{i\} | \text{fixed } L) = \frac{e^{-\beta E(L, \{i\})}}{\sum_{\{i\}} e^{-\beta E(L, \{i\})}}$$

Therefore

$$\frac{d \ln P(L)}{dL} = \beta \left\langle -\frac{dE(L, \xi_i)}{dL} \right\rangle_{\xi_i}$$

Averaging
over all possible
polymers with
length L

$$= \beta \left(\text{mean force by polymer on coordinate } L \right)$$

$$= -\beta \left(\text{mean force applied to the polymer to fix } L \right)$$

$$\int_{L_i}^{L_f} dL \frac{d \ln P(L)}{dL} = \beta \int_{L_i}^{L_f} dL \left\langle -\frac{dE(L, \xi_i)}{dL} \right\rangle_{\xi_i}$$

distance mean force

$$\ln P(L_f) - \ln P(L_i)$$

$$= -\beta W_{rev}$$

Reversible Work Theorem:

$$\frac{P(L_f)}{P(L_i)} = e^{-\beta W_{rev}(L_i \rightarrow L_f)}$$

$$= e^{-\beta [A(L_f) - A(L_i)]}$$

Remember $\ln Q = -\beta A$, so we could also have seen this as

$$\frac{P(L_f)}{P(L_i)} = \frac{Q(L_f)}{Q(L_i)} = \frac{e^{-\beta A(L_f)}}{e^{-\beta A(L_i)}} = e^{-\beta W_{rev}(L_i \rightarrow L_f)}$$

$\underbrace{\qquad}_{\text{ratio of partition functions}}$

↑
Spontaneous fluctuations

↑
Doing work to stretch the polymer

How would I actually compute a change in entropy?
Will I really count the number of microstates?

$$\begin{aligned} S_f - S_i &= - \frac{A_f - A_i - \langle E \rangle_f + \langle E \rangle_i}{T} \\ &= -k_B T \ln \frac{P(L_f)}{P(L_i)} - \frac{\langle E \rangle_f - \langle E \rangle_i}{T} \end{aligned}$$